

**APPLICATION FOR  
UNITED STATES LETTERS PATENT**

**of**

**ERIC STREICHER  
JOHN FOSS  
MAHENDRA L. JOSHI  
and  
HARLEY BORDERS**

**for**

**SYSTEMS AND METHODS FOR INCREASING PRODUCTION OF SPHEROIDAL  
GLASS PARTICLES IN VERTICAL GLASS FURNACES**

Attorney Docket No. 016499-802.001

**BURNS, DOANE, SWECKER & MATHIS, L.L.P.**  
Post Office Box 1404  
Alexandria, VA 22313-1404  
(703) 836-6620

016499-802.001

## SYSTEMS AND METHODS FOR INCREASING PRODUCTION OF SPHEROIDAL GLASS PARTICLES IN VERTICAL GLASS FURNACES

[0001] This application is related and claims priority under 35 U.S.C. § 119(e) to U.S. provisional application serial no. 60/244,658, filed November 1, 2000, the entire contents of which are incorporated by reference herein.

### BACKGROUND OF THE INVENTION

#### Field of the Invention

[0002] The present invention relates to vertically oriented glass furnaces which have been useful for producing spheroidal glass particles, and methods of operation of such furnaces.

#### Brief Description of the Related Art

[0003] Commercial glass particles typically are available in sizes of 10 micrometers to 50 micrometers. They have wide applications such as in electronics, as a reflecting material used in paints (e.g., road signs, roadmarkings), construction material for runways (night landing strips), for grinding/sand blasting applications, injection molding of plastics, etc.

[0004] The glass beads are formed by a variety of methods (see, e.g., U.S. Patent No. 4,961,770). In some cases, electrical and magnetic fields are used for breaking up molten glass streams into large particles and then injecting these particles within the core of a burner flame. The softened glass beads in the high temperature flame zone react and, due to surface tension, form into glass spheres of very small sizes (10 to 50 micrometers).

[0005] In many cases, a very large furnace (e.g., a water or air-cooled vertical reactor) is used for glass bead production (see, e.g., U.S. Patent No. 4,046,548). As shown in Figure 1 herein, the raw material R, which can include crushed glass or cullet in powder form, is fed by devices 110 from a raw material hopper 108 above the air-fuel burner flame region of the vertical reactor 102 of a typical vertical glass furnace 100. The combustion gas stream, which is traveling upwards, immediately entrains the raw material. The suspended glass particles in the high temperature combustion zone soften and, due to surface tension over the glass surface, form into tiny spheres. An average size of the resulting glass particles is dictated by the effective terminal velocity (and therefore residence time) of the particle and the average temperature of the surrounding combustion gases. It can be very important to maintain a uniform temperature profile in the furnace gases to produce a required size distribution for the final glass product.

[0006] The flame gases, and entrained air  $A_i$  from open bottom 122 typically above a floor or ground 124, carry glass particles upward and, upon completion of spheroidizing process, they settle in a large furnace portion 104. The final product P is then conveyed along a product discharge path 120 to a sizing process, where proper size product is packed for shipment. In many cases, about 10% to 15% product remains with the furnace exhaust gas passing through flue 106, which requires additional separation process such as cyclonic separation, a bag house, or electrostatic precipitator (ESP), generally designated 114. Cleaned flue gases leave the separator at a stack 118.

[0007] As illustrated in Figure 1, the recovered product  $P_R$  from the bag-house, etc. 114 is typically recycled to the reactor 102 along a path 116. The furnace can typically process anywhere from 1000 lb/hr (453.6 kg/hr) to 10,000 lb/hr (4,536 kg/hr) of product, depending on the size. The air-fuel burners 112 generally produce a well-mixed bluish flame, which does not have much, if any, visible radiation. This flame also creates outside air infiltration (as shown in

Figure 1)  $A_i$ . The ambient air dilution lowers the average flame gas temperature, but increases overall combustion gas volume. This air infiltration causes two effects as far as the process is concerned:

- [0008] (1) Increasing combustion gas volume, which is necessary for glass particles entrainment and the subsequent spheroidization process. Higher volume means higher entrainment.
- [0009] (2) Lowering of average flame gas temperature, which limits the amount of raw-material which can be processed in the furnace.

[0010] In most cases, the furnace reaches a performance bottleneck, where the maximum raw material feed capacity is reached based on furnace diameter, overall length, total burner firing rate, and outside air entrainment. If additional raw material is added, the spherodizing process is negatively affected and the product quality can degrade and becomes an issue. Here, the product starts agglomerating in lumps due to poor heat transfer, insufficient entrainment, or due to localized hot-spots in the furnace. Most furnace operators therefore do not exceed furnace production capacity due to quality concerns. A need therefore remains to improve vertical glass furnace production levels while permitting glass quality to be retained.

## SUMMARY OF THE INVENTION

[0011] According to a first aspect of the present invention, a process of operating a vertical glass bead furnace, the furnace including a shaft open at the bottom, a raw material addition device, and an air-fuel burner, comprises the steps of firing the air-fuel burner and thereby entraining air into the furnace shaft through the open bottom of the shaft, adding raw material into the furnace, and an

2000 2001 2002 2003 2004 2005 2006 2007 2008 2009 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023 2024 2025 2026 2027 2028 2029 2030 2031 2032 2033 2034 2035 2036 2037 2038 2039 2040 2041 2042 2043 2044 2045 2046 2047 2048 2049 2050 2051 2052 2053 2054 2055 2056 2057 2058 2059 2060 2061 2062 2063 2064 2065 2066 2067 2068 2069 2070 2071 2072 2073 2074 2075 2076 2077 2078 2079 2080 2081 2082 2083 2084 2085 2086 2087 2088 2089 2090 2091 2092 2093 2094 2095 2096 2097 2098 2099 2100 2101 2102 2103 2104 2105 2106 2107 2108 2109 2110 2111 2112 2113 2114 2115 2116 2117 2118 2119 2120 2121 2122 2123 2124 2125 2126 2127 2128 2129 2130 2131 2132 2133 2134 2135 2136 2137 2138 2139 2140 2141 2142 2143 2144 2145 2146 2147 2148 2149 2150 2151 2152 2153 2154 2155 2156 2157 2158 2159 2160 2161 2162 2163 2164 2165 2166 2167 2168 2169 2170 2171 2172 2173 2174 2175 2176 2177 2178 2179 2180 2181 2182 2183 2184 2185 2186 2187 2188 2189 2190 2191 2192 2193 2194 2195 2196 2197 2198 2199 2200 2201 2202 2203 2204 2205 2206 2207 2208 2209 2210 2211 2212 2213 2214 2215 2216 2217 2218 2219 2220 2221 2222 2223 2224 2225 2226 2227 2228 2229 2230 2231 2232 2233 2234 2235 2236 2237 2238 2239 2240 2241 2242 2243 2244 2245 2246 2247 2248 2249 2250 2251 2252 2253 2254 2255 2256 2257 2258 2259 2260 2261 2262 2263 2264 2265 2266 2267 2268 2269 2270 2271 2272 2273 2274 2275 2276 2277 2278 2279 2280 2281 2282 2283 2284 2285 2286 2287 2288 2289 2290 2291 2292 2293 2294 2295 2296 2297 2298 2299 2300 2301 2302 2303 2304 2305 2306 2307 2308 2309 2310 2311 2312 2313 2314 2315 2316 2317 2318 2319 2320 2321 2322 2323 2324 2325 2326 2327 2328 2329 2330 2331 2332 2333 2334 2335 2336 2337 2338 2339 2340 2341 2342 2343 2344 2345 2346 2347 2348 2349 2350 2351 2352 2353 2354 2355 2356 2357 2358 2359 2360 2361 2362 2363 2364 2365 2366 2367 2368 2369 2370 2371 2372 2373 2374 2375 2376 2377 2378 2379 2380 2381 2382 2383 2384 2385 2386 2387 2388 2389 2390 2391 2392 2393 2394 2395 2396 2397 2398 2399 2400 2401 2402 2403 2404 2405 2406 2407 2408 2409 2410 2411 2412 2413 2414 2415 2416 2417 2418 2419 2420 2421 2422 2423 2424 2425 2426 2427 2428 2429 2430 2431 2432 2433 2434 2435 2436 2437 2438 2439 2440 2441 2442 2443 2444 2445 2446 2447 2448 2449 2450 2451 2452 2453 2454 2455 2456 2457 2458 2459 2460 2461 2462 2463 2464 2465 2466 2467 2468 2469 2470 2471 2472 2473 2474 2475 2476 2477 2478 2479 2480 2481 2482 2483 2484 2485 2486 2487 2488 2489 2490 2491 2492 2493 2494 2495 2496 2497 2498 2499 2500 2501 2502 2503 2504 2505 2506 2507 2508 2509 2510 2511 2512 2513 2514 2515 2516 2517 2518 2519 2520 2521 2522 2523 2524 2525 2526 2527 2528 2529 2530 2531 2532 2533 2534 2535 2536 2537 2538 2539 2540 2541 2542 2543 2544 2545 2546 2547 2548 2549 2550 2551 2552 2553 2554 2555 2556 2557 2558 2559 2560 2561 2562 2563 2564 2565 2566 2567 2568 2569 2570 2571 2572 2573 2574 2575 2576 2577 2578 2579 2580 2581 2582 2583 2584 2585 2586 2587 2588 2589 2590 2591 2592 2593 2594 2595 2596 2597 2598 2599 2600 2601 2602 2603 2604 2605 2606 2607 2608 2609 2610 2611 2612 2613 2614 2615 2616 2617 2618 2619 2620 2621 2622 2623 2624 2625 2626 2627 2628 2629 2630 2631 2632 2633 2634 2635 2636 2637 2638 2639 2640 2641 2642 2643 2644 2645 2646 2647 2648 2649 2650 2651 2652 2653 2654 2655 2656 2657 2658 2659 2660 2661 2662 2663 2664 2665 2666 2667 2668 2669 2670 2671 2672 2673 2674 2675 2676 2677 2678 2679 2680 2681 2682 2683 2684 2685 2686 2687 2688 2689 2690 2691 2692 2693 2694 2695 2696 2697 2698 2699 2700 2701 2702 2703 2704 2705 2706 2707 2708 2709 2710 2711 2712 2713 2714 2715 2716 2717 2718 2719 2720 2721 2722 2723 2724 2725 2726 2727 2728 2729 2730 2731 2732 2733 2734 2735 2736 2737 2738 2739 2740 2741 2742 2743 2744 2745 2746 2747 2748 2749 2750 2751 2752 2753 2754 2755 2756 2757 2758 2759 2760 2761 2762 2763 2764 2765 2766 2767 2768 2769 2770 2771 2772 2773 2774 2775 2776 2777 2778 2779 2780 2781 2782 2783 2784 2785 2786 2787 2788 2789 2790 2791 2792 2793 2794 2795 2796 2797 2798 2799 2800 2801 2802 2803 2804 2805 2806 2807 2808 2809 2810 2811 2812 2813 2814 2815 2816 2817 2818

**[0013]** Still other objects, features, and attendant advantages of the present invention will become apparent to those skilled in the art from a reading of the following detailed description of embodiments constructed in accordance therewith, taken in conjunction with the accompanying drawings.

**[0014]** The invention of the present application will now be described in more detail with reference to preferred embodiments of the apparatus and method, given only by way of example, and with reference to the accompanying drawings, in which:

**[0015]** Fig. 1 illustrates a typical vertical glass furnace.

[0016] Fig. 2 illustrates a vertical glass furnace in accordance with a first embodiment of the present invention.

[0017] Fig. 3 illustrates a vertical glass furnace in accordance with a second embodiment of the present invention.

[0018] Fig. 4 illustrates portions of the vertical glass furnace in accordance with the second embodiment of the present invention, illustrated in Figure 3.

[0019] Fig. 5 illustrates a vertical glass furnace in accordance with a third embodiment of the present invention.

[0020] Fig. 6 illustrates portions of the vertical glass furnace in accordance with the third embodiment of the present invention, illustrated in Figure 5.

[0021] Fig. 7 illustrates portions of the vertical glass furnace in accordance with the third embodiment of the present invention, illustrated in Figure 5.

[0022] Fig. 8 illustrates a vertical glass furnace in accordance with a fourth embodiment of the present invention.

[0023] Fig. 9 illustrates a vertical glass furnace in accordance with a fifth embodiment of the present invention.

#### DESCRIPTION OF THE PREFERRED EMBODIMENTS

[0024] Referring to the drawing figures, like reference numerals designate identical or corresponding elements throughout the several figures.

[0025] Within the context of the present invention, the terms “oxygen” and “oxidant” include, but are not limited to: non-pure oxygen, including, but not limited to, oxidants having an oxygen content greater than 21%; oxygen-enriched air; and oxygen-enriched gases wherein the gases are other than pure air.

[0026] One aspect of the present invention relates to several oxygen boost technologies applicable on an air-fuel fired vertical glass furnace for producing spheroidal particles (with glass beads of various sizes). The vertical glass

furnaces use air-fuel combustion burners to produce hot combustion gasses, which rise up from the bottom of the furnace at temperatures of approximately 2000°F to 3000°F. Raw material (e.g., glass in powder form) is fed above the burner location and it is entrained in the upward moving combustion gas stream. The temperature of combustion gases is sufficiently above the softening point of the glass to allow surface tension to subsequently spheroidize the particles. During this spheroidizing process, the glass particles exchange heat energy by conduction (by random collision, fusion with other particles) and through radiation from hot combustion gases.

[0027] In a first exemplary method, the present invention uses an oxidant or oxygen jet at very high velocity from the bottom opening in the furnace. This high velocity oxidant or oxygen injection causes an ejector effect and entrains a very large amount of ambient air, up to 100 to 300 times in volume of the injected oxygen, from the bottom opening in the furnace. The oxygen enriched air mixes with air-gas burner combustibles to create flame gases at slightly higher temperature. This increase in air-gas flame temperature and additional entrainment of ambient air from the bottom create a faster spheroidization process.

[0028] In a second exemplary method, an oxy-fuel burner is fired upward at the same bottom location as an oxygen lance to create fuel-rich, luminous, and high-temperature oxy-fuel flame. The firing rate of the oxy-fuel burner can be adjusted anywhere from about 5% to 60% of the total furnace firing rate.

[0029] In a third exemplary method, the present invention uses multiple oxygen lances upstream of the air-fuel burner. The increased radiation of the (oxy-fuel) flame and subsequent mixing of oxy-fuel products of combustion with air-fuel products of combustion gases increase final gas temperatures. The temperature uniformity of the resulting combustion gases results in an increased spheroidization rate and therefore increased productivity. Production increases from 50% to 200% can be achieved over conventional air-fired systems.

[illegible]

**[0032]** The location of an oxygen lance 202 can be very important from the overall process point of view. The lance is strategically located in the center of



**THE**  
**NEW**  
**YORK**  
**PUBLIC**  
**LIBRARY**

[0034] The amount of oxygen injected can be varied to accommodate the operating parameters of the furnace. For example, the flow rate can be between about 200 scfh (standard cubic feet per hour) and about 30,000 scfh, depending on the size, overall firing rate, and production rate of the furnace. The oxygen proportion injected can be between about 5% and about 30% of the theoretical oxidant needed for the air-fuel burners. The oxygen flow is adjusted to either increase or decrease overall flame gas temperatures for a desired bead quality and production rate. Those of skill in the art are very familiar with the considerations

given to the adjustment of these furnace parameters, and will therefore not be further detailed herein.

[0035] The air-fuel burners 112, of which there are typically several positioned around the furnace wall, are generally fired at a constant firing rate, whereas the amount of oxygen flow from injection through lance 202 is adjusted to optimize the bead quality. The bead quality is generally assessed or expressed by the spherical shape of the product P. These beads are generally passed through a rolling sphere test. The rolled beads vs. non-spherical (difficult to roll) beads' relative weight percentages are measured to assess bead quality. A second test involves measuring the mesh number of the beads using various sieves. The beads are typically made for certain sieve number (40, 60, etc.).

[0036] II. Oxy-fuel burner firing: Another aspect of the present invention involves oxy-fuel burning performed upstream of the air-fuel burners 112, as illustrated in Figure 3. The oxy-fuel burner flame  $F_{OF}$  stoichiometry (oxidant/fuel ratio, R) is adjusted such that it is always on the rich side. The preferred ratio range is  $0.5 \leq R \leq 2.00$ . The rich firing generates a large amount of carbon monoxide (CO), unburnt fuel, soot and other hydrocarbons. The subsequent combustion of these products creates a very luminous flame. The visible flame radiation provides uniform heat transfer to the glass particles without creating hotspots.

[0037] The location of one or more oxy-fuel burners 302 can also be very important from the overall process point of view. The burner is strategically located in the center of the furnace 300 at the bottom, and the location of the burner is dependent on the oxy-fuel flame length. As shown in Figure 3, the oxy-fuel flame  $F_{OF}$  is centered and it gradually merges with the products of combustion from air-fuel combustion. The gradual mixing provides an increase in flame gas temperature in a uniform fashion. The resulting flame gases travel upwards with increased radiative properties. The visible radiation of this flame produces

[illegible]

**[0039]** III. Multiple oxygen lances upstream of the air-fuel burner: Yet another aspect of the present invention involves multiple oxygen lances upstream of the air-fuel burner(s). According to this aspect of the present invention, multiple lances 402 are positioned fluidly before the air-fuel burners in the entrained air stream to inject oxygen streams into the air-fuel burner flame. One embodiment of such as oxygen injection system and method 400 is illustrated in Figures 5 and 6.

**[0040]** The injection method is very specific to distribute oxygen gradually into the flame root (at very low injection velocity, e.g., between about 1 ft/s (0.30 m/s) and about 100 ft/s (30.5 m/s)). This relatively low injection velocity is preferably used to prevent immediate mixing of oxygen in the air-fuel flame core and creation of hot spots. The gradual oxygen injection allows slower mixing and more uniform subsequent flame gas temperature profile. The objective of this

oxygen injection is to increase average flame gas temperatures (and heat release rate) for additional glass particle processing. The amount of oxygen lancing can be anywhere from about 1000 scfh to 50,000 scfh, depending on the furnace production capacity. The above can result in between 21.5% to 60% enrichment of the combustion air necessary for the air-fuel burners.

[0041] The implementation of the techniques described herein, either individually or together, can result in increased furnace capacity to process glass particles. Without being limited to a particular range, it is estimated that 50% to 200% increases in production can be obtained using techniques in accordance with the present invention. An additional advantage of the above techniques is the ability to retrofit oxygen burner and lance equipment without long-term furnace shutdown. The capital costs of the above systems are also very low compared to a furnace rebuild for larger capacity.

[0042] IV. Lances inserted into the air-fuel burners: A further aspect of the present invention includes at least one, and preferably multiple lances inserted into the air-fuel burners, as illustrated schematically in Figure 8. This injection system 500 and method allows oxygen injection directly into the air-fuel flame  $F_{AF}$  to increase its temperature. The injection is done into each burner using an oxidant lance 502 to allow a homogeneous oxygen distribution within the flame to avoid hot spots. The injection is done at low velocity, e.g., between about 30 ft/s (9.15 m/s) and about 100 ft/s (30.49 m/s), for reasons similar to those presented above. Those of skill in the art are well acquainted with various configurations of lances in air-fuel burners, and details thereof will not be included here so as not to obscure the present invention.

[0043] V. Oxygen injection utilizing an injection ring: Yet another aspect of the present invention includes utilization of an oxygen injection ring 602, such as that illustrated in Figure 9, to inject oxygen below the air-fuel flame. Oxygen mixes with the air entrained at the bottom of the furnace to participate in

combustion. The air flowing through the air-fuel burner 112 can be reduced to achieve higher flame temperatures. This system and method facilitates the mixing of air with oxygen to generate an homogeneous flame temperature. The oxygen injection velocity is preferably between about 30 ft/s (9.15 m/s) and about 200 ft/s (61 m/s). As illustrated in Figure 9, the oxidant is supplied to the ring 602 via appropriate supplies 604.

[0044] The injection ring is advantageously positioned at a vertical distance H (see Fig. 7) from the air-fuel burner center axis. H is preferably between about 6 inches (15.25 cm) and 36 inches (0.91 m), depending on the size of the furnace 600. The outside diameter of the oxygen injection ring 602 should be adjusted to the furnace geometry. For example, the ratio  $D_R/D_F$  can be anywhere on the range 0.2 to 0.9, wherein  $D_R$  is the outer diameter of the oxygen injection ring, and  $D_F$  is the inner diameter of the furnace shaft 102.

[0045] According to yet further aspects of the present invention, the oxygen lances and oxy-fuel burner preferably are formed of metallic materials. They have a periscope shape (90° outlet) to reduce exposure of burner parts (such as oxygen and fuel inlets) to thermal radiation and also facilitate burner installation. It is preferably mounted on a structural frame member, so it can be pulled out of the firing or injection position using a simple sliding mechanism.

[0046] During single oxygen lance operation or during multiple oxygen lance operation, the air-fuel burner equivalence ratio is adjusted between about 0.7 and about 1.00 (i.e., fuel-rich), and the remaining oxidant for combustion is supplied through the oxygen lance and entrained ambient air from the bottom of the furnace.

[0047] During oxy-fuel burner firing, the oxy-fuel burner firing stoichiometry is adjusted anywhere between about 0.5 and about 2.00 (oxidant/fuel ratio). The oxy-fuel burner velocities are adjusted to give a very long, lazy, and luminous flame. The oxy-fuel burner products of combustion are allowed to mix with the

030420650

air-fuel burner products of combustion. The resulting mixture has very highly visible radiation and offers higher overall heat transfer to the entrained glass particles.

[0048] The firing of an oxy-fuel burner also increases the amount of entrained air from the bottom of the furnace. Thus, the overall combustion gas volume is increased to match the increase in flame gas temperature. The net effect is higher glass particle entrainment capacity of the furnace gases. In addition, due to oxy-fuel burner products of combustion (water, CO<sub>2</sub>, CO, soot particles, unburnt fuel, and other hydrocarbons) a very luminous flame is obtained, in contrast to a bluish or non-luminous flame generated by air-fuel burners. The water and CO<sub>2</sub> components due to oxy-fuel firing also offer higher effective heat transfer to the glass particles.

[0049] The single oxygen lance, oxy-fuel burner, or both, can be installed anywhere in the furnace shaft from about 2 feet (0.61 m) to 12 feet (3.66 m) below the air-fuel burner. The distance between oxygen lance/oxy-fuel burner and air-fuel burner depends on the oxygen injection rate, the oxy-fuel burner firing rate, or both. An objective for the single oxygen lance is to create good entrainment of ambient air underneath the furnace and create good mixing with the combustibles from air-fuel burner. An objective of the oxy-fuel flame is to minimize excessive penetration into the horizontally fired air-fuel burner flame.

[0050] The oxy-fuel burner can be oxy-gas (e.g., oxygen-natural gas) fired or can be oxygen-fuel oil (e.g. Diesel, bunker-C, etc.) fired, for example, depending on the availability and economics of secondary fuel. In the case of oxy-fuel oil firing, the resulting flames can be of higher visible radiation compared to oxy-gas firing. This should translate into even higher capacity to process glass particles.

[0051] The oxygen lance aspect of the present invention is followed in a manner which is consistent with oxy-fuel burner firing. The lance approach can

be utilized simultaneously with the oxy-fuel burner approach. An exemplary oxygen lance is illustrated in Figure 6.

[0052] As illustrated in Figure 6, the oxygen lance 402 can be made out of high temperature alloy, refractory material, other similar high temperature material. The lance insertion length (L) is adjustable to obtain an optimum radial injection point for appropriate flame temperature development. The lance exit 416 has an internal diameter (D) selected to give an average injection velocity between about 1 ft/s (0.3 m/s) and about 100 ft/s (30.5 m/s).

[0053] The oxygen injection velocities are kept lower to delay combustion and prevent any hotspots in the air-fuel flame structure. This is illustrated in Figure 7, where the injected oxygen stream  $J_{O_2}$  travels radially outward by riding on the underside of the air-fuel flame F. The oxygen is consumed (by reacting with combustibles in the air-fuel flame) as it travels radially outward. The oxygen jet penetration is prevented by selecting an appropriate nozzle diameter (D). The low velocity oxygen is injected at the air-fuel flame root, and it is immediately dragged towards the flame tip due to air-fuel burner radial momentum. The advantage of low velocity oxygen injection is to delay combustion or allowing a controlled combustion due to the presence of oxygen. The controlled combustion can prevent excessive air-fuel flame temperatures and also uniform flame temperature profile, qualitatively shown in the schematic of Figure 7.

[0054] The vertical height (H) and the lance insertion point (L) are adjusted in consideration of the air-fuel burner firing rate and flame characteristics. As shown in Figure 7, the height (H) can be anywhere from about 6 inches (15.25 cm) to about 36 inches (0.91 m), and the insertion length (L) can be between about 2 inches (5.08 cm) and about 48 inches (1.22 m), depending on the furnace shell internal diameter.

[0055] The oxygen injection can be performed at an axis  $Y_O$  other than  $90^\circ$  (see Figure 6). The injection angle  $\alpha$  can be varied between about  $0^\circ$  and about

80° to suit air-fuel burner flame characteristics, by corresponding changes in the geometry of the lance 402, including elbow 408, or reorientation of the lance relative to the furnace.

[0056] The number of oxygen lances can be same as the number of air-fuel burners according to yet further aspects of the present invention, or it can be higher to suit additional injection of oxygen gas. The oxygen can be supplied from an oxygen header or manifold 404, as shown in Figure 5. From the header 404, the oxygen is then uniformly distributed to all individual lances using a flexible hose connection. The flex hose 412 is then connected by a quick disconnect device 410 to install or remove lance from the furnace wall 126.

[0057] Various aspects of the present invention can have a number of benefits in vertical glass furnaces. Oxygen boosting by lance, burner, or both, can be retrofitted into an existing air-fuel fired reaction chamber, including those which are air or water cooled.

[0058] By boosting the combustion process with oxygen equivalent to 5% to 60% of the theoretical amount required for complete combustion, an increase in the furnace production from 50% to 200% can be realized, the defect rate can decrease by 50%, and the percentage of spherical to non-spherical product can increase to greater than 90%.

[0059] While the invention has been described in detail with reference to preferred embodiments thereof, it will be apparent to one skilled in the art that various changes can be made, and equivalents employed, without departing from the scope of the invention. All of the aforementioned documents are incorporated by reference in each of their entireties herein.